

**Code lock drilling
template - 50x50 tube**

Check both 100 mm bars.

1. Cut solid edges, crease folds.
2. LOCK EDGE on mortice side.
3. Spindle line at lever height.
4. Punch, pilot drill, drill.

#	Hole	Height*	Face
1	Ø6.5	+112	Lever
2	Ø25	0	Lever
3	Euro cyl.	-85	Lever
4	Ø6.5	-122	Lever
5	2x Ø3	+77.75	Edge
5	2x Ø3	-142.25	Edge
6	Slot 17x173.5	+54.5 to -119	Edge

* mm from spindle centre (+ up)

