







FULL CONTROL
BOARD MANUAL

<https://www.bft-automation.com/qrcodemanual/D814457>

DEIMOS BT B 400 DEIMOS BT B 600





D814457_04A_04 26-01-26



IT	LINGUA ORIGINALE
EN	TRANSLATED VERSION
FR	VERSION TRADUITE
DE	ÜBERSETZTE VERSION
ES	VERSIÓN TRADUCIDA
NL	VERTAALDE VERSIE
PT	VERSÃO TRADUZIDA
EL	ΜΕΤΑΦΡΑΣΜΕΝΗ ΕΚΔΟΣΗ

PL	WERSJA TŁUMACZONA
RU	ПЕРЕВОДНАЯ ВЕРСИЯ
CS	PŘEKLOŽENÁ VERZE
TR	ÇEVİRİLEN VERSİYON
HR	PREVEDENA VERZIJA.
RO	VERSIUNE TRADUS


النسخة المترجمة AR



IT	Verifica la tua composizione nell'etichetta imballo.
EN	Check your composition on the packaging label
FR	Vérifiez votre composition sur l'étiquette d'emballage.
ES	Controla la composición de tu kit en la etiqueta del embalaje
DE	Überprüfen Sie Ihre Zusammenstellung auf dem Verpackungsetikett.
NL	Controleer uw samenstelling op het verpakingslabel.
PT	Verifique a composição no rótulo da embalagem
EL	Ελέγξτε τη σύνθεση του κιτ στην ετικέτα της συσκευασίας
PL	Prosimy sprawdzić zawartość zestawu na etykiety opakowania
RU	Проверьте компоновку на этикетке упаковки.
CS	Zkontrolujte složení sady na štítku obalu.
TR	Ambalaj etiketindeki bileşiminizi kontrol edin
HR	Na etiketi provjerite sastav svojeg paketa
RO	Verificați-vă compoziția de pe eticheta ambalajului

تحقق من التركيبة في ملصق العبوة


AR



DEIMOS BT B 400	DEIMOS BT B 600
-----------------	-----------------


	220-230 V 50/60 Hz	
P stand-by	0,43 W	
Pmax	80 W	100 W
	433,92 MHz	
IP	24	
	44	special
	-20°C / +55°C	
cycles/h	25	
	<70 dBA	
Speed max	16 m/min	14 m/min
	200 kg-20 Nm	300 kg-30 Nm
	400 kg-20 Nm	600 kg-30 Nm

Example





>25 mm




50 mm

25 mm

65 mm

Ø 10 mm







140 mm

(IT) Cemento
(FR) Ciment
(DE) Zement
(PT) Cimento
(PL) Spoiwo
(CS) Cement
(HR) Cement

(EN) Concrete
(ES) Cemento
(NL) Cement
(EL) Τσιμέντο
(RU) Цемент
(TR) Çimento
(RO) Ciment
(AR) بيني


1






4


A




B



5




6




Sinistra
Left
Gauche
Links
Izquierda
Links
Esquerda
Αριστερά
Leva
Лево
Vlevo
Sol
Lijevo
Stânga
اليسار

L




Destra
Right
Droite
Rechts
Derecha
Rechts
Direita
Δεξιά
Prawo
Πραβο
Vpravo
Sağ
Desno
Dreapta
اليمن


R




7





IT	APERTURA COPERTURA SCHEDA	NL	KAARTAFDEKKING OPENEN	CS	OTEVÍRÁNÍ KRYTU KARTY
EN	OPENING BOARD COVER	PT	ABERTURA COBERTURA PLACA	TR	KART KAPLAMASININ AÇILMASI
FR	OUVERTURE DU COUVERCLE DE LA CARTE	EL	ΑΝΟΙΓΜΑ ΚΑΛΥΜΜΑΤΟΣ ΚΑΡΤΑΣ	HR	OTVARANJE POKLOCA PLOČE
DE	ÖFFNUNG KARTENABDECKUNG	PL	OTWIERANIE OSŁONY KARTY	RO	DESCHIDEREA CAPACULUI DULAPULUI
ES	APERTURA CUBIERTA TARJETA	RU	ОТКРЫТИЕ КРЫШКИ ПЛАТЫ	AR	جاري فتح غطاء اللوحة



IT	CHIUSURA COPERTURA SCHEDA	NL	KAARTAFDEKKING SLUITEN	CS	ZAVÍRÁNÍ KRYTU KARTY
EN	CLOSING BOARD COVER	PT	FECHE COBERTURA PLACA	TR	KART KAPLAMASININ KAPANMASI
FR	FERMETURE DU COUVERCLE DE LA CARTE	EL	ΑΝΟΙΓΜΑ ΚΑΛΥΜΜΑΤΟΣ ΚΑΡΤΑΣ	HR	ZATVARANJE POKLOCA PLOČE
DE	SCHLIESSUNG KARTENABDECKUNG	PL	ZAMYKANIE OSŁONY KARTY	RO	ÎNCHIDEREA CAPACULUI DULAPULUI
ES	CIERRE CUBIERTA TARJETA	RU	ЗАКРЫТИЕ КРЫШКИ ПЛАТЫ	AR	جاري إغلاق غطاء اللوحة








LEGENDA - LEGENDE - LEGEND - LEYENDA - ΥΠΟΜΝΗΜΑ - УСЛОВНЫЕ ОБОЗНАЧЕНИЯ - ANLAMLAR - أسطورة



RADIO

Diagnostica radio
Radio diagnostics
Diagnostic radio
Diagnose der Funksteuerung
Diagnóstico radio
Radiodiagnose
Diagnóstico rádio
Διάγνωση ασυρμάτου
Diagnostyka radiowa
Радиодиагностика
Rádiová diagnostika
Radyo tanılama
Radiodijagnostika
Diagnosticare radio
صات بموجات الراديو




+

Aggiungi start
Add Start Key
Ajouter Touche Start
Hinzufügen Taste Start
Añadir Tecla start
Toets start toevoegen
Adiciona Tecla start
Προσθήκη Μπουτόν start
Dodaj Przycisk Start
Добавить клавишу Start (Пуск)
Přidej tlačítko start
Start tuşu ekle
Dodaj tipku Start
Adăugarea tastei Start
إضافة مفتاح بدء



SET

Diagnostica stato scheda
Board status diagnostics
Diagnostic état de la carte
Karten-Status-Diagnose
Diagnóstico estado tarjeta
Diagnose van de status van de printplaat
Diagnóstico estado placa
Διάγνωση κατάστασης πλακέτας
Diagnostyka stanu płytki drukowanej
Диагностика состояния монтажной платы
Diagnostika stavu desky plošných spojů
Devre kartı durum tanılama
Dijagnostika stanja ploče
Diagnosticarea stării plăcii
تشخيصات حالة اللوحة




-

Aggiungi secondo canale radio
Add second radio channel
Ajouter Deuxième canal radio
Hinzufügen eines zweiten Funkkanals
Agregar Segundo canal radio
Tweede radiokanaal toevoegen
Adicionar Segundo canal de rádio
Προσθήκη δεύτερου ραδιοδιαύλου
Dodaj drugi kanał radiowy
Добавить Второй радиоканал
Přidat druhý kanál rádia
İkinci radyo kanalı ekle
Dodaj drugi radiokanal
Adăugarea unui al doilea canal radio
إضافة قناة راديو ثانية




ERR





Diagnostica errori
Error diagnostics
Diagnostic erreurs
Fehler-Diagnose
Diagnóstico errores
Storingsdiagnose
Diagnóstico erros
Διάγνωση σφαλμάτων
Diagnostyka błędów
Диагностика ошибок
Diagnostika chyb
Hata tanılama
Dijagnostika grešaka
Diagnosticare erori
تشخيصات الأخطاء




AR الفتح إلى اليمين




AR الفتح إلى اليسار




10 AUTOSET



12



13









END



IT	MANOVRA MANUALE
EN	MANUAL OPENING
FR	OUVERTURE MANUELLE
ES	APERTURA MANUAL
DE	MANUELLE ÖFFNUNG
NL	HANDMATIGE OPENING
PT	ABERTURA MANUAL
EL	ΧΕΙΡΟΚΙΝΗΤΟ ΑΝΟΙΓΜΑ



PL	OTWIERANIE RĘCZNE
RU	РУЧНОЕ ОТКРЫТИЕ
CS	MANUÁLNÍ OTEVÍRÁNÍ
TR	MANUEL AÇMA
HR	RUČNO OTVARANJE
RO	DESCHIDERE MANUALĂ
فتح يدوي	AR



IT	Attenzione! Non spingere VIOLENTEMENTE l'anta del cancello.
EN	Warning! Do not push the gate WITH EXCESSIVE FORCE
FR	Attention! Ne poussez pas VIOLEMMENT le vantail du portail.
ES	¡Atención! No empuje CON VIOLENCIA la hoja de la puerta.
DE	Achtung! Schieben Sie den Torflügel nicht MIT GEWALT an.

NL	Let op! Duw niet MET GEWELD tegen de deur van het hek.
PT	Atenção! Não empurrar COM FORÇA a folha do portão.
EL	Προσοχή! Μην σπρώχνετε ΜΕ ΜΕΓΑΛΗ ΔΥΝΑΜΗ το φύλλο της πύλης.
PL	Uwaga! Nie należy GWAŁTOWNIE popychać skrzydła bramy.
RU	Внимание! Не толкайте СЛИШКОМ СИЛЬНО створку ворот.

CS	Pozor! Na křídlo brány netlačte PRÍLIŠNOU SILOU.
TR	Dikkat! Kapının kanadını ŞİDDETLİ bir şekilde itmeyin.
HR	Nemojte gurati vrata uz primjenu PREKOMJERNE SILE!
RO	Nu împingeți bariera CU FORȚĂ EXCESIVĂ.
AR	لا تدفع البوابة بقوة زائدة



AZIENDA CON
SISTEMA DI GESTIONE
CERTIFICATO DA DNV GL
= ISO 9001 =
= ISO 14001 =



8 027908 811981 >

