

REMOOTIO) PRO

4 WAYS FOR USERS TO OPEN

1 PHONE APP

- Bluetooth
- Wi-Fi
- Internet
- Ethernet



2 APP-FREE KEY

Open the gate instantly via secure QR code or web browser link.




No app installation required.




3 KEYPAD PIN CODE

Enter PIN code on keypad.



4 RFID CARD

Tap RFID card or tag.



ACCESS RIGHTS YOU CAN DEFINE



USAGE COUNTS

Limit how many times a user can operate the gate.

Max Uses

2

- ✓ Delete key when max usage is reached



TIME RESTRICTION

Set one-off or reoccurring date & time windows for user permissions

- ✓ Set limitation from a certain date to another
From 01 June 2026 08:00 To 05 June 2026 18:00
- ✓ Set limitation based on weekly recurring pattern
Monday 09:00 - 18:00



OUTPUT RESTRICTION

Customize output name and choose which output(s) with NO / NC connection the user is allowed to operate

- ✓ Main gate
- ✓ East gate
- ☐ Garage



WEB DASHBOARD

Web dashboard access for managing user & group access rights from a computer



BLUETOOTH ACCESS ✓



WI-FI ACCESS ✓



INTERNET ACCESS ✓



PIN CODE ACCESS ✓



RFID CARD ACCESS ✓



CAMERA ACCESS ✓



NOTIFICATION WHEN KEY IS USED ✓



ADMIN ONLY PRIVILEGES ✓



LICENSE PLATE RECOGNITION (LPR) CAMERA ✓

EXAMPLE USE CASES

RESIDENTS



Mobile app access (bluetooth / wifi / internet)



Unlimited access

DELIVERY STAFF



APP-free link / QR code valid for 1 use



Max Use: 1
Usage count

CLEANING STAFF



Keypad PIN code access during working hours



08:00 - 17:00
Weekdays

MAINTENANCE TEAM



RFID Card access restricted to specific gates



Output 1 &
Output 3 only

REMOOTIO) PRO


GROUPS & ACCESS RULES

HOW USERS ARE IN GROUPS

Organize users into groups and define access rights for each group.

Group restrictions apply to every user inside that group. If a user's personal rights are wider, the group restrictions still apply.


DEVICE OWNER



ADMIN USER ROLES & PERMISSIONS

ROLE	PERMISSIONS	WHEN IN A GROUP
Access-rights-only admin	• Can edit access rights of other non-admin users	Can only edit users' access in that group
Regular admin	• Can edit access rights of other non-admin users • Can edit device settings	Can only edit users' access in that group
Super admin	• Can edit access rights of other non-admin users • Can edit device settings • Can edit other admin users • Can see and edit all groups	Can manage all groups & admin users
Device owner	• Everything Super Admin can do • Can reset device from the app • Rights cannot be revoked or altered	Can manage all groups & admin users and reset device

ADMIN HIERARCHY



API INTEGRATION

WEB-BASED API INTEGRATION



Integrate Remootio Pro into your own system.

Our web-based API allows you to control the device and manage users programmatically.

API CAPABILITIES


Basic

- ✓ Open / close the gate
- ✓ Check status if open or closed
- ✓ Operate any of the device's outputs

Advanced

- ✓ Create new user / group
- ✓ Edit key / group access rights
- ✓ Access and read log of events

HOW IT WORKS



EXAMPLE USE CASES

RESIDENTIAL BUILDING / GATED COMMUNITY

Residents (one group per apartment / household)



- ✓ One group per apartment
- ✓ Apartment owner is access-only admin that can manage access of own family & guests

2. CLEANING / MAINTENANCE / GARDENING TEAM

Staff (one group per team)



- ✓ Can only access during work days & hours
- ✓ Restricted to on-site access methods only (no internet / remote access)

3. HOTEL PARKING / PARKING LOT / OFFICE BUILDING CAMPUS / GYM / CAR RENTAL



- ✓ Create groups for different user types
- ✓ Give varied access to guests, employees, vendors
- ✓ Integrate with your hotel system via our API

REMOOTIO) PRO


EXAMPLE USE CASE DESCRIPTIONS

1 ONE-TIME ACCESS: e.g. Delivery, Guests, Pet Sitter


- ✓ Create one-time PIN code or QR code
- ✓ Random PIN or QR code
- ✓ Maximum uses = 1
- ✓ Delete user after max use



ADMIN SETUP




HOW IT WORKS




2 TIME-LIMITED ACCESS: e.g. Hotel, Parking lot, Car Rental, Gym, Private Membership Facility


- ✓ Create a user (optionally with integrated API)
- ✓ Give a PIN code / RFID card / App-free key QR code or link
- ✓ Access limited between two dates



ADMIN SETUP



HOW IT WORKS



3 GROUP ACCESS MANAGEMENT: e.g. Residential building, Gated Community, Office campus, Factory Warehouse

- ✓ One group per apartment
- ✓ Access-only admin for each apartment (owners manage their own users)
- ✓ Maintenance / gardening group with restricted & time-limited access



GROUP STRUCTURE & ACCESS SETUP

APARTMENT GROUPS (one group per apartment)

Group: Apt 101

- Owner (access-only admin)
- Family members & temporary guests

Group: Apt 102

- Owner (access-only admin)
- Family members & temporary guests

Group: Apt 103

- Owner (access-only admin)
- Family members & temporary guests

Access-only admin (the owner) can:

- Create users for family / temporary guests
- Max users / group can be set by who created the groups
- Set PIN code, usage limits, time limits etc. for their group
- Cannot see or change other groups or device settings

GARDENING TEAM GROUP

Group: Gardening Team



Access methods enabled:



Time Limitations:



HOW IT WORKS

For Apartment Owners

They manage access for their apartment group such as:



For Gardening Team

- Their access can be limited to:
- On-site (Bluetooth/PIN/RFID)
 - During certain days & hours

REMOOTIO) PRO

LICENSE PLATE RECOGNITION (LPR) CAMERA INTEGRATION

LPR CAMERA INTEGRATION



Integrate Remootio Pro with your LPR camera


Up to 3 cameras can be interfaced with Remootio Pro.

Configure each camera to send webhooks to the device over your local network or the internet.

LPR CAPABILITIES

- ✓ Each user can have one or more license plates assigned to them.
- ✓ Toggle license plate access on or off for individual users or groups.
- ✓ Remootio Pro opens the gate when the camera detected a license plate assigned to a user that has access to the gate.
- ✓ Set time limits for when Remootio Pro is allowed to open the gate based on License Plate Recognition (e.g. no LPR access during night).
- ✓ **Automatic License Plate Recognition (ALPR) / License Plate Learning feature:** Remootio Pro can learn and remember the license plates of users who open the gate via the app, PIN code, or RF card. Next time they approach, the gate can open automatically using their license plate alone.

HOW IT WORKS



EXAMPLE USE CASES of LPR CAMERA INTEGRATION

1 MANUAL INPUT OF LICENSE PLATE: e.g. Gated community, Residential building, etc.

- ✓ Add license plate number to the user info
- ✓ Set access period (no expiry or date range)
- ✓ Control access by time, group, or usage limit



ADMIN SETUP

1 Create User



Name
John
Group
Building A Residents

2 Add License Plate number(s)

ABC123

You can add multiple license plates to a user if needed

3 Set Access Options

Access period
☒ No expiry
☐ Date range

Access control
☒ LPR access granted for user's group
☒ LPR access granted for the individual user

HOW IT WORKS

Vehicle with registered plate approaches gate

Camera reads license plate (e.g. ABC123)

✓ System verifies access and gate opens

2 AUTOMATIC LICENSE PLATE RECOGNITION (ALPR) / LICENSE PLATE LEARNING FEATURE: e.g. Hotel, parking garage, parking lot etc.

- ✓ No manual input of license plate
- ✓ Learns the plate after guest uses given access method for first visit
- ✓ Works automatically on subsequent visits
- ✓ Set validity period (e.g. 1 week)

HOW IT WORKS: FIRST VISIT - PLATE LEARNING

1 Vehicle arrives at hotel parking barrier



EFG567

Camera detects license plate EFG567

2 Guest enters using given access method



Within the learning period, guest opens the gate using PIN code, RFID card or mobile

3 Gate opens



Gate opens for the guest

4 License plate is learned and saved



License Plate
EFG567
Expiry
1 week

The system automatically saves the detected license plate to the user with an expiry date.

SUBSEQUENT VISITS (IN VALIDITY) - AFTER PLATE HAS BEEN LEARNED

1 Guest returns to hotel parking



EFG567

Camera detects license plate EFG567

2 System checks access rights

Access period
☐ No expiry
☒ Date range

Access control
☒ LPR access granted for user's group
☒ LPR access granted for the individual user

3 Gate opens automatically



Gate opens using License Plate Recognition

4 License plate expires after set period



The license plate will automatically expire after the configured time (e.g. 1 week)

